
LED Recessed Down Light Instruction

Please read this instruction carefully before installation

This instruction applies to Recessed Down Light



Cautions

- 1.Outdoor Lamp connect to the power: 220-240 VAC, 50-60Hz
- 2.Use only rated power (see power label)
- 3. For your safety, please disconnect the electricity before installation/maintenance/replacement.
- 4. Do not operate until the light cool down.
- 5.Do not connect electricity until the light is installed properly
- 6. Make sure at least a 75mm ventilation around the frame. The distance between light fixture and object not less than 500mm, Don't use the light fixture against fire regulations.
- 7. Do not install the light fixture to thea ceiling that is easily damaged or deformed.
- 8. Do not cover the light fixture with any heat proof gasket or similar materials.
- 9. If any abnormal situation occurrs, Please turn off power immediately, and contact our service or consign to the professional engineer.
- 10. Any question about this instruction, please contact us or consult qualified engineer.